



#	Part	QTY.
1	402-4020, Endlink, Rear, Mk7 S3	2
2	402-Z010, Spacer, Endlink, Rear Swaybar Upper, Mk7 S3	2
3	402-Z011, Spacer, Endlink, Rear Swaybar Lower, Mk7 S3	4
4	H00-M10x1.50x50-10.9	2
5	H22-M10x1.50-FL-ZC	2
6	H22-M8x1.25-FL-ZC	2

If you feel that you can not properly install this product, we highly recommend you take the vehicle to a qualified and experienced automotive technician.

Contact 034Motorsport 9:00 AM - 6:00 PM PST weekdays for questions regarding fit or instructions that are not clear to you. Your 034Motorsport part was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, contact 034Motorsport.

Use of product may not be legal on public roads. Please check with local authorities prior to installation. Use of product may void warranty.